



OIL SANDWICH ADAPTER INSTRUCTIONS

Part #'s: 1313, 1320, 1322, 1350, 1358 & 1327

BEFORE INSTALLING THIS TRANS-DAPT OIL SANDWICH ADAPTER, MEASURE CLEARANCE BEHIND THE FACTORY FILTER. ALLOW FOR THICKNESS OF THE ADAPTER PLUS 3/4" FOR FILTER REMOVAL.

1. Remove factory oil filter from engine.
2. Install sandwich adapter on factory filter landing with the appropriate O-ring installed in the adapter.
3. Screw sleeve nut on factory filter nipple until snug.
4. Position adapter in direction desired; tighten with wrench to about 25 foot pounds of torque.
5. Install oil cooler (not included) as per manufacturer's instructions.
6. Reinstall factory oil filter.

CAUTION:

1. *If filter O-ring is flush with rim of filter, rim may hit adapter first, not allowing a good seal. This may occur with Japanese brands. Select another brand.*
2. *DO NOT OVERTIGHTEN cooler lines when connecting to the sandwich adapter.*

16410 Manning Way • Cerritos, CA 90703 • tel (562) 921-0404 • fax (562) 921-7515

oil-sandwich-adapter-instructions.cdr